

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 1: Manual A/C Circuit (1 of 2)

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 3: Anti-lock Brakes Circuit, W/ VSC (1 of 2)

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla

ANTI-THEFT

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 8: Body Control Modules Circuit

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 10: Cooling Fan Circuit

DEFOGGERS

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 17: 1.8L, Engine Performance Circuit, Except XRS (4 of 4)

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 26: Horn Circuit

POWER MIRRORS

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 38: Power Windows Circuit

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 40: Radio Circuit, W/O Amplifier

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla




Fig. 42: Charging Circuit

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla





Fig. 49: Warning Systems Circuit

2006 Toyota Corolla LE

2006 SYSTEM WIRING DIAGRAMS Toyota - Corolla



206073

Fig. 50: Wiper/Washer Circuit