




A63
Skid Control ECU Assembly







Note:
Please refer to the Multiplex Communication System (CAN) section for information regarding the shielded communication lines.

ABS, Hill-Start Assist Control, TRC, VSC




Air Conditioner







A47(A), A48(B)
FC Control ECU




z25(A), z26(B), z27(C), z28(D), z29(E), z30(F), z31(G), z32(H), z33(I), z34(J), z35(K), z36(L), z37(M), z38(N), z39(O), z40(P),
 z41(Q), z42(R), z43(S), z44(T), z45(U), z46(V), z47(W), z48(X), z49(Y), z50(Z), z51(a), z52(b), z53(c), z54(d), z55(e)
 Fuel Cell (FC Stack Assembly)



u1(A), z18(B), z19(C), z20(D), z21(E), z22(F), z23(G), z24(H)
 FC Stack Voltage Sensor (FC Stack Assembly)




z25(A), z26(B), z27(C), z28(D), z29(E), z30(F), z31(G), z32(H), z33(I), z34(J), z35(K), z36(L), z37(M), z38(N), z39(O), z40(P),
 z41(Q), z42(R), z43(S), z44(T), z45(U), z46(V), z47(W), z48(X), z49(Y), z50(Z), z51(a), z52(b), z53(c), z54(d), z55(e)
 Fuel Cell (FC Stack Assembly)




Front Wiper and Washer

G32
Windshield Wiper Relay Assembly




Ground Point (LHD)




Ground Point (LHD)


PV1
White




Pa1
White




Pn1
White




QZ1
White




RP2
White




WG1
Gray



WG2
White




XQ1
Black




Ground Point (RHD)

* 1 : w/o Seat Heater
 * 2 : w/ Seat Heater




Ground Point (RHD)

GP1
White




90980-12874




90980-12873


GQ1
White



90980-12874



90980-12873



A27(A), G45(C), G46(D)
EV Control ECU

