



Power Source (Except Korea) (Before Oct. 2015 Production)




Multiplex Communication System (CAN RHD) (Before Oct. 2015 Production)




Engine Control (3ZR-FE, 3ZR-FAE) (Before Oct. 2015 Production)

* 1 : 3ZR-FE
 * 2 : 3ZR-FAE
 * 18 : Before Apr. 2015 Production
 * 19 : From Apr. 2015 Production




ECT and A/T Indicator (2AR-FE) (Before Oct. 2015 Production)

* 1: A/T




19	10
----	----

Power Window (RHD) (Before Oct. 2015 Production)




Door Lock Control (Korea) (Before Oct. 2015 Production)

*26 : w/ Power Seat




Multiplex Communication System (CAN LHD) (From Oct. 2015 Production)



Cruise Control
(3ZR-FE, 3ZR-FAE)
(From Oct. 2015 Production)

CVT and Shift Indicator (3ZR-FE, 3ZR-FAE) (From Oct. 2015 Production)



Cruise Control (2AD-FHV, 2AD-FTV)
(From Oct. 2015 Production)

36

Wiring diagram for the Diesel Turbo Pressure Sensor and Cruise Control system.


Legend:

- * 3 : w/o Air Fuel Ratio Sensor
- * 4 : w/ Air Fuel Ratio Sensor
- * 9 : w/ Cruise Control
- *10 : A/T

Components and Connections:


- Diesel Turbo Pressure Sensor (B47):**
 - VC (VCPM) to 93 (E)
 - PIM to 117 (E)
 - E (EPIM) to 72 (E)
 - VC to 3
 - PIM to 2
 - E to 1
- Differential Pressure Sensor Assembly (B71):**
 - PEX to 2
 - E2 to 1
 - VC to 3
 - VC to 93 (E)
 - PIM to 117 (E)
 - E to 72 (E)
- Cruise Control Main Switch (z4(F)):**
 - ON-OFF switch
 - +RES switch
 - SET switch
 - CANCEL switch
- Cruise Control Sub-Assembly (G8(A)):**
 - CCS to 23 (A)
 - ECC to 2 (A)
 - AG1 to 12 (A)
 - AG14 to 21 (A)
 - AG14 to 18 (A)
 - AG14 to 8 (A)
 - AG14 to 10 (A)
 - AG14 to 6 (A)
 - AG14 to 4 (A)
 - AG14 to 2 (A)
 - AG14 to 1 (A)
 - AG14 to 3 (A)
 - AG14 to 4 (A)
 - AG14 to 6 (A)
 - AG14 to 8 (A)
 - AG14 to 10 (A)
 - AG14 to 12 (A)
 - AG14 to 14 (A)
 - AG14 to 16 (A)
 - AG14 to 18 (A)
 - AG14 to 20 (A)
 - AG14 to 22 (A)
 - AG14 to 24 (A)
 - AG14 to 26 (A)
 - AG14 to 28 (A)
 - AG14 to 30 (A)
 - AG14 to 32 (A)
 - AG14 to 34 (A)
 - AG14 to 36 (A)
 - AG14 to 38 (A)
 - AG14 to 40 (A)
 - AG14 to 42 (A)
 - AG14 to 44 (A)
 - AG14 to 46 (A)
 - AG14 to 48 (A)
 - AG14 to 50 (A)
 - AG14 to 52 (A)
 - AG14 to 54 (A)
 - AG14 to 56 (A)
 - AG14 to 58 (A)
 - AG14 to 60 (A)
 - AG14 to 62 (A)
 - AG14 to 64 (A)
 - AG14 to 66 (A)
 - AG14 to 68 (A)
 - AG14 to 70 (A)
 - AG14 to 72 (A)
 - AG14 to 74 (A)
 - AG14 to 76 (A)
 - AG14 to 78 (A)
 - AG14 to 80 (A)
 - AG14 to 82 (A)
 - AG14 to 84 (A)
 - AG14 to 86 (A)
 - AG14 to 88 (A)
 - AG14 to 90 (A)
 - AG14 to 92 (A)
 - AG14 to 94 (A)
 - AG14 to 96 (A)
 - AG14 to 98 (A)
 - AG14 to 100 (A)

ABS, Auto LSD, Downhill Assist Control, Hill-Start Assist Control, TRC and VSC
(From Oct. 2015 Production)



Seat Heater (Driver' s Seat and Front Passenger' s Seat) (From Oct. 2015 Production)

* 1 : w/ Power Seat
 * 2 : w/o Power Seat



Automatic Air Conditioner (From Oct. 2015 Production)

